

# MECHANICAL VACUUM PUMP SYSTEM FOR STEEL DEGASSING

[edwardsvacuum.com](http://edwardsvacuum.com)

## MECHANICAL VACUUM PUMP

**Vacuum Degassing (VD) and Vacuum Oxygen Decarburisation (VOD) are often used in the production of speciality steel alloys. They are used to reduce the levels of hydrogen, carbon and other impurities during the secondary steel making process.**

Historically large multi-stage steam ejector systems, backed with liquid ring pumps, have been used. However, these are energy inefficient, rely on high steam quality for consistent performance, and cause foreline dust deposits that develop into "cakes" making cleaning difficult.

Steel degassing in tanks or in the ladle involves two basic processes: Vacuum Degassing (VD) and Vacuum Oxygen Decarburising (VOD). For these processes two types of vacuum pump system have been operated over the past 25 years.

- The steam ejector system uses multi-stage high pressure steam ejectors usually supported by water sealed Liquid Ring pumps.
- The alternative mechanical system uses multi-stage mechanical boosters supported by completely dry primary vacuum pumps.

The completely dry pump system has proven to be the most effective. The cost saving is significant, as shown over the page. There are also metallurgical benefits from the elimination of back-streaming of water vapour.

Combined with the better ultimate vacuum, this leads to reduced residual hydrogen in the metal. Faster evacuation and more flexible operational characteristics allow for closer



chemistry control. This leads to more consistent formulation and opportunities for new steel qualities.

All maintenance costs are reduced, including cost for cleaning the pumps and pipework. The waste disposal costs for the dry dust are also reduced, or the dust can be recycled reducing costs further and limiting the impact on the environment.

## WHY MECHANICAL PUMPS?

### Cost saving

Energy costs reduced by over 90%

### Reduced maintenance

Elimination of fore line deposits

### Reduced effluent costs

Easier disposal or recycling of dry waste

### Reduced cycle times

Vacuum on demand

### Consistent processing

Reliable and dependable vacuum level

### Better steel quality

Lower hydrogen levels achieved in VD

### Improved stainless quality

Better VOD control

### New steel qualities

Easier control of chemistry

**OPERATING COST COMPARISON:****Dry mechanical vacuum pumps vs. steam ejectors**

Melt mass (tonnes) = 60

Boiler size (kg/h) = 10000

Production tonnage = 300.000

Process = VD

Cycle time in vacuum (mins) = 25

Cost criterion	Condition		Specific cost		Steam ejectors			Dry running pumps including filter operating costs			
<b>Consumption</b>											
- steam	12 bar, 194°C	20,00	€/t	69,4	kg/t	1,3888889	€/t				
- contact water	3 bar, 32°C	0,04	€/m <sup>3</sup>	4,5	m <sup>3</sup> /t	0,1805556	€/t				
- non-contact water	4 bar, 32°C	0,03	€/m <sup>3</sup>					0,0875000	m <sup>3</sup> /t	0,0026250 €/t	
- compressed air	5 bar	0,02	€/m <sup>3</sup>					0,0002500	m <sup>3</sup> /t	0,0000050 €/t	
- nitrogen	5 bar	0,10	€/m <sup>3</sup>					0,0550000	m <sup>3</sup> /t	0,0055000 €/t	
- gear box oil		3,00	€/liter					0,0004400	liter/t	0,0013200 €/t	
- power (pumps+auxiliaries)		0,05	€/kWh	0,69	kWh/t	0,0347222	€/t	0,3750000	kWh/t	0,0187500 €/t	
Subtotal consumption						1,6041667	€/t			0,0282000 €/t	
<b>Maintenance</b>											
	€ per hour	man hours									
- pump service	35,00	4	140,00	€/pump	5000	tappings	0,0014000	€/t	5000	tappings	0,0042000 €/t
- pump cleaning	35,00	40	1400,00	€/job	200	tappings	0,1166667	€/t			
- heat exchanger cleaning	35,00	12	420,00	€/job					5000	tappings	0,0000003 €/t
- filter bag changing	35,00	8	280,00	€/job					2083	hours	0,0000011 €/t
- dust disposal			0,00	€/t	0,00	kg/t	0,0000000	€/t	0,20	kg/t	0,0000000 €/t
- contact water disposal			1,00	€/m <sup>3</sup>	0,45	m <sup>3</sup> /t	0,4513889	€/t			
Subtotal maintenance							0,5694556	€/t			0,0042014 €/t
<b>Spares</b>											
	€ each	number									
- filter bags	15,00	216	3240,00	€/change					0,0000033	sets/ton	0,0000000 €/t
- seals and bearings	2000,00	per installed pump			3	pumps	0,0100000	€/t	9	pumps	0,0300000 €/t
Subtotal spares							0,0100000	€/t			0,0300000 €/t
TOTAL							2,1836222	€/t			0,0624014 €/t
Difference							0,0000000	€/t			2,1212209 €/t
Annual saving									Saving	636	k€

Operating costs	Steam ejectors	Dry running pumps including filter
	€/ton	€/ton
Energy and fluids	1,6041667	0,0282000
Maintenance	0,5694556	0,0042014
Spares	0,0100000	0,0300000
TOTAL	2,1836222	0,0624014
Maintenance	0%	97%

**GLOBAL CONTACTS**

Publication Number: 3602 570 0 01  
 © Edwards Limited 2020. All rights reserved  
 Edwards and the Edwards logo are trademarks of Edwards Limited

Whilst we make every effort to ensure that we accurately describe our products and services, we give no guarantee as to the accuracy or completeness of any information provided in this datasheet.

Edwards Ltd, registered in England and Wales  
 No. 6124750, registered office: Innovation Drive,  
 Burgess Hill, West Sussex, RH15 9TW, UK.

**EMEA**  
**UK** +44 1444 253 000  
 (local rate) 08459 212223  
**Belgium** +44 (0) 1293 60 3350  
**France** +33 1 4121 1256  
**Germany** 0800 000 1456  
**Italy** + 39 02 48 4471  
**Israel** + 972 8 681 0633  
**Russia** + 749 5 933 5550  
 Ext. 1800/1803  
 + 880 0 775 8099

**ASIA PACIFIC**  
**China** +86 400 111 9618  
**India** +91 20 4075 2222  
**Japan** +81 47 458 8836  
**Korea** +82 31 716 7070  
**Singapore** +65 6546 8408  
**Taiwan** +886 3758 1000

**AMERICAS**  
**USA** +1 800 848 9800  
**Brazil** +55 11 3952 5000

